

Typical Sump-pump Installation

In our opinion this is the typical sump pump installation that should be installed for an excessive sub-area water condition which can not be drained by natural (gravity) drainage.

Every situation will vary and each installation should be designed by the installer to meet the specific conditions involved.

Based on the hundreds of installations, which we have inspected, those with the following components and installation methods are properly maintained, provide proper drainage and provide the ongoing functionality and life expectancy you should expect.

